



How to Reverse Hinges

Hinge Direction—Right or Left?




Hinge set for right hand operation




Hinge set for left hand operation

Instructions for converting cam-lift hinge operating direction. (Edgemount door hinges).



How To Reverse Hinge Direction.

Remove pin and rotate the hinge butt and blade. You will need to restack any bearings or washers. The hinge blade should turn on top of the bearings. Replace the hinge pin to complete reversing hinge. Hinge pin should always be inserted from top side of hinge.



Instructions for converting cam-lift hinge operating direction. (Strap-type door hinges).

